GSM/GPRS/GPS Tracker **GV320**

User Manual

TRACGV320UM001

Revision: 1.02

Document Title	GV320 User Manual
Version	1.02
Date	2012-08-14
Status	Release
Document Control ID	TRACGV320UM001

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai Queclink Wireless Solutions Co., Ltd. 2011

Contents

1 Introduction 7
1.1. Reference 7
1.2. Terms and Abbreviations 7
2 Product Overview 8
2.1. Check Part List 8
2.2. Parts List 9
2.3. Interface Definition 9
2.4. GV320 User Cable Colour 11
3 Getting Started 12
3.1. Opening the Case 12
3.2. Closing the Case 12
3.3. Installing a SIM Card 13
3.4. Installing the Internal Backup Battery 13
3.5. Switch ON the Backup Battery 14
3.6. Installing the External GPS Antenna (Optional) 14
3.6.1. GPS Antenna Specification 15
3.7. Power Connection 15
3.8. Ignition Detection 15
3.9. Digital Inputs 16
3.10. Analog Inputs 17
3.11. Digital Outputs 17
3.12. Device Status LED 19
3.13. Serial Port / UART Interface 20

Queclink Confidential

Table Index

TABLE 1. GV320 PROTOCOL REFERENCE 7
TABLE 2. TERMS AND ABBREVIATIONS 7
TABLE 3. PART LIST 9
TABLE 4. DESCRIPTION OF 16 PIN CONNECTIONS 10
TABLE 5. GV320 USER CABLE COLOUR DEFINITION 11
TABLE 6. GPS ANTENNA SPECIFICATION 15
TABLE 7. ELECTRICAL CHARACTERISTICS OF IGNITION DETECTION 15
TABLE 8. ELECTRICAL CHARACTERISTICS OF THE DIGITAL INPUTS 16
TABLE 9. ELECTRICAL CHARACTERISTICS OF DDIGITAL OUTPUTS 18
TABLE 10. DEFINITION OF DEVICE STATUS AND LED 19

Queclink Confidential

Figure Index

FIGURE 1. APPEARANCE OF GV320 8
FIGURE 2. THE 16 PIN CONNECTOR ON THE GV320 10
FIGURE 3. OPENING THE CASE 12
FIGURE 4. CLOSING THE CASE 12
FIGURE 5. SIM CARD INSTALLATION 13
FIGURE 6. BACKUP BATTERY INSTALLATION 13
FIGURE 7. SWITCH AND ON/OFF POSITION 14
FIGURE 8. GPS ANTENNA OF GV320 14
FIGURE 9. TYPICAL POWER CONNECTION 15
FIGURE 10. TYPICAL IGNITION DETECTION 16
FIGURE 11. TYPICAL DIGITAL INPUT CONNECTION 17
FIGURE 12. TYPICAL ANALOG INPUT CONNECTION 17
FIGURE 13. DIGITAL OUTPUT INTERNAL DRIVE CIRCUIT 18
FIGURE 14. TYPICAL CONNECTION WITH RELAY 18
FIGURE 15. TYPICAL CONNECTION WITH LED 19
FIGURE 16. GV320 LED ON THE CASE 19
FIGURE 17. TYPICAL CONNECTION WITH RS232 PORT 21

Queclink Confidential

Revision History

Revision	Date	Author	Description of change
1.01	2012-05-07	Owen Feng	Initial
1.02	2012-08-14	Leaf Ye	Add uart Garmin connection

Queclink Confidential

1 Introduction

The GV320 is a powerful GPS locator designed for vehicle or asset tracking. It has superior receiver sensitivity, fast TTFF (Time to First Fix) and supports Dual-Band GSM frequencies 850/1900, its location can be monitored in real time or be periodically tracked by a backend server or other specified terminals. The GV320 has multiple input/output interfaces that can be used for monitoring or controlling external devices. Based on the integrated @Track protocol, the GV320 can communicate with a backend server through the GPRS/GSM network to transfer reports of Emergency, geo-fence boundary crossings, low backup battery or scheduled GPS position as well as many other useful functions. Users can also use GV320 to monitor the status of a vehicle and control the vehicle by its external relay output. System Integrators can easily setup their tracking systems based on the full-featured @Track protocol.

This device complies with part 15B, part 22 and part 24 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference

(2) this device must accept any interference, including interference that may cause undesired operation.

1.1. Reference

Table 1. GV320 Protocol Reference

SN	Document name	Remark
[1]	GV320 @Track Air Interface Protocol	The air protocol interface between GV320 and backend server.

1.2. Terms and Abbreviations

Table 2. Terms and Abbreviations

Abbreviation	Description
AGND	Analog Ground
AIN	Analog Input
DIN	Digital Input
DOUT	Digital Output
GND	Ground
MIC	Microphone
RXD	Receive Data
TXD	Transmit Data
SPKN	Speaker Negative
SPKP	Speaker Positive

Queclink Confidential

2 Product Overview

2.1. **Check Part List**

Before starting, check all the following items have been included with your GV320. If anything is missing, please contact your supplier.

Figure 1. Appearance of GV320

Queclink Confidential

2.2. **Parts List**

Table 3. Part List

Name	Picture
GV320 Locator	80*49*26 mm
User Cable	
Extend Cable (Optional)	
GPS Antenna (Optional)	
DATA_CABLE_M (Optional)	

2.3. **Interface Definition**

The GV320 has a 16 PIN interface connector. It contains the connections for power, I/O, RS232, microphone, speaker, etc. The sequence and definition of the 16PIN connector are shown in following figure:

Queclink Confidential



Figure 2. The 16 PIN connector on the GV320

Table 4. Description of 16 PIN Connections

Index	Description	Comment
1	MICP	Single end, 2-2.2k microphone, internal bias
2	AGND	Analog ground
3	IGN	Ignition input, positive trigger
4	RXD	UART RXD, RS232
5	TXD	UART TXD, RS232
6	GND	Power and digital ground
7	OUT3	Open drain, 150mA max
8	OUT2	Open drain, 150mA max
9	EARP	Differential output, 32ohm 1/4w speaker
10	EARN	
11	PWR	External DC power input, 8-32V
12	IN2	Digital input, negative trigger
13	IN1	Digital input, negative trigger
14	OUT1	Open drain, 150mA max ,with latch circuit
15	AD1/IN3	Multifunction input, analog or digital input 0-16V
16	AD2	Analog input 0.3-16v

Queclink Confidential

2.4. **GV320 User Cable Colour**

Table 5. GV320 User Cable Colour definition

Definition	Color	PIN No	Cable	PIN No	Color	Definition
OUT2	Yellow	8		16	Brown/White	AD2
OUT3	Brown	7		15	Green	AD1/IN3
GND	Black	6		14	Blue	OUT1
TXD	White/Black	5		13	Orange	IN1
RXD	Green	4		12	Orange/Black	IN2
IGN	White	3		11	Red	PWR
AGND	Gray/ Black	2		10	Purple/White	EARN
MICP	Gray	1		9	Purple	EARP

Queclink Confidential

3 Getting Started

3.1. Opening the Case

Figure 3. Opening the Case

Insert the triangular-pry-opener into the gap of the case as shown below, push the opener up until the case unsnapped.

3.2. Closing the Case

Figure 4. Closing the Case

Place the cover on the bottom in the position as shown in the following figure. Slide the cover against the direction of the arrow until it snapped.

Queclink Confidential

3.3. Installing a SIM Card

Open the case and ensure the unit is not powered (unplug the 16Pin cable and switch the internal battery to off position). Slide the holder right to open the SIM card. Insert the SIM card into the holder as shown below with the gold-colored contact area facing down taking care to align the cut mark. Close the SIM card holder. Close the case.



Figure 5. SIM Card Installation

3.4. Installing the Internal Backup Battery

Figure 6. Backup Battery Installation

There is an internal backup Li-ion battery,

3.5. Switch ON the Backup Battery

To use the GV320 backup battery, the switch must be at the ON position. Switch on the case and ON/OFF position are shown below.

Figure 7. Switch and ON/OFF position

Note:
1-The switch must be on the “OFF” position when shipped on an aircraft.
2-When the switch is on the “OFF” position, the battery cannot be charged or discharged.

3.6. Installing the External GPS Antenna (Optional)

There is a SMA GPS antenna connector on GV320. The GV320 will automatically detect and use an external antenna when connected.

Figure 8. GPS Antenna of GV320

3.6.1. GPS Antenna Specification

Table 6. GPS Antenna Specification

GPS antenna:	Frequency: 1575.42MHz
Bandwidth:	>5MHz
Beam width:	>120 deg
Supply voltage:	2.7V-3.3V
Polarization:	RHCP
Gain:	Passive: 0dBi min Active: 15dB
Impedance:	50Ω
VSWR:	<2
Noise figure:	<3

3.7. Power Connection

PWR (PIN12) / GND (PIN6) are the power input pins. The input voltage range for this device is from 8V to 32V. The device is designed to be installed in vehicles that operate on 12V or 24V systems without the need for external transformers.



Figure 9. Typical Power Connection

3.8. Ignition Detection

Table 7. Electrical Characteristics of Ignition Detection

Logical State	Electrical State

Active	5.0V to 32V
Inactive	0V to 3V or Open



Figure 10. Typical Ignition Detection

IGN (Pin3)is used for ignition detection. It is strongly recommended to connect this pin to ignition key “RUN” position as shown up.

An alternative to connecting to the ignition switch is to find a non permanent power source that is only available when the vehicle is running. For example the power source for the FM radio.

IGN signal can be configured to start transmitting information to backend server when ignition is on; and enter power saving mode when ignition is off.

3.9. Digital Inputs

There are three general purpose digital inputs on GV320. They are all negative trigger.

Table 8. Electrical Characteristics of the digital inputs

Logical State	Electrical Characteristics
Active	0V to 0.8V
Inactive	Open

The following diagram shows the recommended connection of a digital input.

Confidential



Figure 11. Typical Digital Input Connection

3.10. **Analog Inputs**

There are two analog inputs on GV320, the analog input voltage range is from 0 to 16V. The following diagram shows the recommended connection.



Figure 12. Typical Analog Input Connection

Note:

PIN 15 is an multifunction pin: it can be configured as a digital input or an analog input.

3.11. **Digital Outputs**

There are three digital outputs on GV320. All are of open drain type and the maximum drain current is 150 mA. Each output has the built-in over current and recovery PTC fuse



Figure 13. Digital Output Internal Drive Circuit

Table 9. Electrical Characteristics of Ddigital Outputs

Logical State	Electrical Characteristics
Enable	<1.5V @150mA
Disable	Open drain



Figure 14. Typical Connection with Relay



Figure 15. Typical Connection with LED

Note:

1 - OUT1 will latch the output state during reset.

2- All outputs are internally pulled up to PWR pin by a diode. So no external flyback diode is needed when the output is connected to an inductive load.

3.12. Device Status LED



Figure 16. GV320 LED on the Case

Table 10. Definition of Device status and LED

Note:

LED	Device status	LED status
GSM (note1)	Device is searching GSM network	Fast flashing (Note3)
	Device has registered to GSM network.	Slow flashing (Note4)
	SIM card needs pin code to unlock.	ON
GPS (note 2)	GPS chip is powered off	OFF
	GPS sends no data or data format error.	Slow flashing
	GPS chip is searching GPS info.	Fast flashing
	GPS chip has gotten GPS info.	ON
PWR (note 2)	No external power and internal battery voltage is lower than 3.35V.	OFF
	No external power and internal battery voltage is below 3.5V.	Slow flashing
	External power in and internal battery is charging	Fast flashing
	External power in and internal battery is fully charged	ON

1 - GSM LED cannot be configured.

2 - GPS LED and PWR LED can be configured to turn off after a period of time using the configuration tool

3 - Fast flashing is about 60ms ON/ 780ms OFF

4 - Slow flashing is about 60ms ON/ 1940ms OFF

3.13. Serial Port / UART Interface

There are two lines dedicated to the Serial Port / UART interface (TXD and RXD).TXD / RXD are standard RS232 signal.

Queclink Confidential



Figure 17. Typical Connection with RS232 Port

3.13.1 Connect With Garmin GPS Set

GV320 can communicate with Garmin GPS Set. The following typical connection is using Queclink AG100 cable.

Figure 1. GV320 connection with Garmin GPS set

Note: GV320 some version maybe connects with Garmin GPS set by Garmin FMI10/FMI15 cable, please consult with Queclink for detail information.